


ELECTRICAL CONNECTION


LINEAR-18 ELITE (WITH DRL)

Customer's have the option to connect to a positive battery or ignition feed. Connecting to the ignition feed, the light will only operate with the ignition turned on.




LINEAR-18 ELITE I-LBA

Customer's have the option to connect to a positive battery or ignition feed. Connecting to the ignition feed, the high beam function will only operate with the ignition turned on.



LINEAR-18 ELITE+

Customer's have the option to connect to a positive battery or ignition feed. Connecting to the ignition feed, the light will only operate with the ignition turned on.



TRIPLE-R
HIGH PERFORMANCE LIGHTING

A LAZER LAMPS COMPANY

TOYOTA TACOMA TRD
(2024+) GRILLE KIT
FITTING INSTRUCTIONS



TRIPLE-R
HIGH PERFORMANCE LIGHTING

WWW.TRIPLE-R-LIGHTS.COM

We appreciate your purchase of a Triple-R Lights' product, and value your feedback. If you would like to leave feedback on your Triple-R experience, please head to the relevant product page on our website www.triple-r-lights.com.

sales@triple-r-lights.com

Triple-R Lights LLC, 600 North Bullard Avenue,
Suite 6, Goodyear, AZ 85338
UNITED STATES

UK BUILT | US DRIVEN    /TRIPLERLIGHTS


WHAT'S INCLUDED

- 2x Grille Mounting Brackets
- 2x Cutter Guides
- Anti-Theft Fasteners & Key
- Fitting Instructions

Additionally - Kit Includes:


- 1x Linear-18 LED Lightbar
- 1x One-Lamp Wiring Kit

TOOLS REQUIRED



TORQUE VALUES

The code is written on the inside of each bracket (see example).



INSTALLATION PROCESS - Install should be completed with the grille left on the vehicle.

